



Pairing Sensors in Kinetic Fit (Android)


First be sure you have Bluetooth enabled on your device. Then, the android app pairs as follows:




From the home screen, select the menu on the top left




Select "Sensors"



Select chain link icon. Paired sensors show a connected link.



There are four pairing options: speed, cadence, and power and heart rate



Pairing summary shows which sensor will be transmitting data.

There are four pairing options: speed, cadence, and power are paired with your trainer, heart rate is paired with a BLE heart rate strap.

Tap any of the icons below the sensor listing to toggle them on or off.

3rd-party BLE speed/cadence sensors are also paired here. If one is installed on your bike and not in sleep mode, it will show up on the "Sensors" screen.

Pairing status summary appears above the sensor list